

# NEVERREACH Go! INSTALLATION INSTRUCTIONS

(Required tools: 3mm Allen key, scissors)



## 1. Mount bracket to seat rail

Place the Top fitting bracket plate behind the bicycle seat rails and the Lower connector bracket positioned in front of the seat rails. Using a 5mm Allen Key screw the Lower connector bracket to the Top fitting bracket using the M5 screws.



## 2. Attach adaptor to bracket



CAUTION: MAKE SURE A 'CLICKING SOUND' IS HEARD WHEN ATTACHING ADAPTOR TO BRACKET. IF NO SOUND IS HEARD THEN GENTLY LIFT UP ON THE ADAPTOR'S RELEASE TAB UNTIL THE CLICK SOUND IS HEARD.

Note: to detach adaptor press down on release tab as shown on the right picture.



### 3. Attach liquid container to adaptor

Attach the liquid container to the adaptor by sliding the ball's taper mount over the adaptor.

Slide the rubber ring over the ball's taper mount as illustrated. Note: the rubber ring may not be necessary when riding on flat surfaces.



### 4. Connect tube holder to bicycle's handlebars

Attach tube holder to handlebars using securing strap. Insert tube into tube holder and secure with smaller strap and adjust to desired position. If tube strap does not fit around handlebars, replace with extra securing strap.

Note: If using aerobars, you may use the extra securing strap to attach the tube directly to the aerobars. The tube holder must attach to the handlebars.



## 5. Attach tubing to liquid container's spigot

Measure the tubing along bicycle's frame so the end fits completely over the liquid container's spigot. Use scissors to cut off any excess tubing. Insert spigot into tubing so that spigot's ridges are completely covered by the tubing for a secure fit.



**CAUTION:** We recommend cutting the tube a little too long and then trimming the tube as needed so that the tube is not too short.

## 6. Use straps to secure the tubing to the bicycle's horizontal bar



**CAUTION:** DO NOT WRAP THE STRAPS AROUND THE BRAKE LINE.

## 7. Fill the container with desired liquid

## 8. Attach cap to liquid container



**CAUTION:** REMOVE CAP PRIOR TO TRANSPORTING ON A CAR WITH SPEEDS EXCEEDING 40 MPH TO PREVENT CAP FROM COMING OFF.

## 9. Bite down on the mouthpiece to receive liquid

### DRAINING INSTRUCTIONS

Take off cap, and then hold a bottle under the spigot while disconnecting the tube. The tube can be stored under the seat while the contents of the container are drained. Next, bite down on the mouthpiece and blow all excess liquid into the bottle. Keep the tube disconnected from the container and allow the tube to dry in a warm location so mold does not develop.



### CLEANING INSTRUCTIONS

The liquid container and tube should be cleaned after each use by hand as needed using mild soap and water. The easiest way to clean the tube is to add soap from one end of the tube, blow the liquid out, than repeat from the other tube end. All liquid must be blown from the tube and disconnected from the container to dry completely, see instructions above. If mold develops, we recommend soaking all plastic components in the sink using a 5-minute denture cleaner tablet to remove any excess build-up.

NOTE: AVOID USING ANY ABRASIVE BRUSHES THAT COULD SCRATCH THE UNIT.

### WARRANTY

All NeverReach components are guaranteed to be defect free for 30 days from date of customer purchase. Any return of defective components must be accompanied by customer's original sales receipt along with defective item for immediate replacement. (Note: in the event NeverReach will not properly mount, a full refund will be given minus shipping charges for the complete unused unit with sales receipt.)

**NRZ, Inc.**  
**963 Topsy Lane, Ste. 306-229**  
**Carson City, NV 89705**  
**(866) 305-3753**

### TECHNICAL SUPPORT

All questions should be sent to [info@neverreach.com](mailto:info@neverreach.com), or call Toll Free (866) 305-3753.

[WWW.NEVERREACH.COM](http://WWW.NEVERREACH.COM)